

## **Check list for shutdown Experiments**

Stop run Turn off motherboard Ramp down CAEN HV Ramp down Tenelec Ramp down  
MCP target and MCP Turn off thermocouple Turn off PLC power Warm up cooler  
temperature to ~15 deg